


Marina Power & RV Park Equipment

Parts Handbook Volume VI



Powering Business Worldwide



1-800-723-8009

www.marinapower.com

EATON CORPORATION

Table of Contents

Parts

Power	7
Connections	27
Lighting	33
Water	36
Housing	38

Additional information

Warranty Policy	43
Maintenance and Cleaning	45

The Most Complete, Highest Quality, Electrical Distribution Equipment for Marina and RV Park Applications.

Known as a leader in power pedestals and electrical distribution products and services, Eaton is a quality driven company that constantly looks for ways to provide enhanced products and service solutions for their customers. Eaton can provide marina and rv park developers a complete electrical solution. For more information on our products, visit us online at www.marinapower.com.

What Eaton Has to Offer:

- We offer complimentary comprehensive in-house electrical designs for your complete development using all high quality products by Eaton.
- We can provide your development with complete remote wireless digital electronic meter reading.
- Not only can Eaton provide your development with the highest quality power pedestals and distribution equipment, we can also supply you with all of the electrical needs for your surrounding development from lighting, safety switches to loadcenters to wire and beyond.



Lighthouse® / Powerhouse®




Hatteras®



Newport Camp Mate /
Harbor Mate

How to Buy Online?



Marina Power and Lighting

Please contact our experienced sales staff today, to learn more about the highest quality marina power equipment on the market!

All transactions through Eaton's e-store are covered under Eaton's selling policy 25-000.








Toll Free: (800) 723-8009






Phone: (757) 258-8800

Email: marinasales@eaton.com









Description	Catalog #
	<p>Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral</p> <p>Complete single phase copper bus bar assembly</p> <p>MPL1140A</p>
	<p>Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral</p> <p>Complete 3F copper bus bar assembly</p> <p>MPL1140FA</p>
	<p>Newport Harbor Mate / Newport Camp Mate • Hatteras Light</p> <p>Complete single phase copper bus bar assembly</p> <p>MPLNP1108A</p>
	<p>Newport Harbor Mate / Newport Camp Mate • Hatteras Light</p> <p>Complete 3F copper bus bar assembly</p> <p>MPL1108FA</p>
	<p>Newport Harbor Mate / Newport Camp Mate • Hatteras Light</p> <p>Complete single phase aluminum mechanical bus bar assembly</p> <p>MPL1108MA</p>
	<p>Newport Harbor Mate / Newport Camp Mate • Hatteras Light</p> <p>Complete 3F aluminum mechanical bus bar assembly</p> <p>MPL1108MFA</p>
	<p>Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral</p> <p>Complete single phase aluminum mechanical bus bar assembly 350MCM</p> <p>MPL1140MA</p>
	<p>Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral</p> <p>Complete 3F aluminum mechanical bus bar assembly 350MCM</p> <p>MPL1140MFA</p>









Power

	Description	Catalog #
	Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral Copper bus bar with nuts and washers 2" x 1" x 1/4"	MPL3471
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light Copper bus bar with nuts and washers 1 1/4" x 7/10" x 3/16"	MPLNP3468
	Firehouse Double barrel terminal block (Firehouse bus bar)	MPL3751
	Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral Mechanical lug bus bar up to 300MCM	MPL300MCM
	Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral Mechanical lug bus bar up to 350MCM	MPL350MCM
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light Bus bar holder	MPL1000
	Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral Bus bar holder	MPL1100




Description	Catalog #	
	Meter Kits	MPL18E20
120V single element meter kit, 1-side, black counter		MPL18E20C
120V single element meter kit, 1-side, clear counter		MPL18E200
120V single element meter kit, 2-side, black counter		MPL18E200C
120V single element meter kit, 2-side, clear counter		MPL18E21
120/240V dual element meter kit, 1-side, black counter		MPL18E21C
120/240V dual element meter kit, 1-side, clear counter		MPL18E22
120/240V dual element meter kit, 2-side, black counter		MPL18E22C
120/240V dual element meter kit, 2-side, clear counter		MPL18E23
120/208V three element meter kit, 1-side, black counter		MPL18E23C
120/208V three element meter kit, 1-side, clear counter		MPL18E24
480V three element meter kit, 1-side, black counter		MPL18E24C
480V three element meter kit, 1-side, clear counter		MPL18E25
277/480V three element meter kit, 1-side, black counter		MPL18E25C
277/480V three element meter kit, 1-side, clear counter		MPL18E2P1
Power wire extensions (for new installations)		
		
	Meter Kits (Quick Connect Style Wiring)	MPL18E20-R
120V Single element meter kit, 1-side, black counter		MPL18E20C-R
120V Single element meter kit, 1-side, clear counter		MPL18E200-R
120V Single element meter kit, 2-side, black counter		MPL18E200C-R
120V Single element meter kit, 2-side, clear counter		MPL18E21-R
120/240V Dual element meter kit, 1-side, black counter		MPL18E21C-R
120/240V Dual element meter kit, 1-side, clear counter		MPL18E22-R
120/240V Dual element meter kit, 2-side, black counter		MPL18E22C-R
120/240V Dual element meter kit, 2-side, clear counter		MPL18E23-R
120/208V Three element meter kit, 1-side, black counter		MPL18E23C-R
120/208V Three element meter kit, 1-side, clear counter		MPL18E24-R
480V Three element meter, 1-side, black counter		MPL18E24C-R
480V Three element meter, 1-side, clear counter		MPL18E25-R
277/480V three element meter kit, 1-side, black counter		MPL18E25C-R
277/480V three element meter kit, 1-side, clear counter		
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht Counter (Screw in/black)	MPL3021
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht Counter (Snap in/clear)	MPL3021C






Power

	Description	Catalog #
	Lighthouse/Lighthouse SS 20A GFCI-00 amber faceplate	MPL1120
	Lighthouse/Lighthouse SS 30A-00 amber faceplate	MPL1129
	Lighthouse/Lighthouse SS 30A-20GFCI amber faceplate	MPL1121
	Lighthouse/Lighthouse SS 30A-50A amber faceplate	MPL1122
	Lighthouse/Lighthouse SS 30A-30A amber faceplate	MPL1127
	Lighthouse/Lighthouse SS 50A-50A amber faceplate	MPL1123
	Lighthouse/Lighthouse SS 50A-20GFCI amber faceplate	MPL1124
	Lighthouse/Lighthouse SS 20GFCI-20GFCI amber faceplate	MPL1125

Description	Catalog #	
	Lighthouse/Lighthouse SS 00-00 amber faceplate	MPL1126
	Lighthouse/Lighthouse SS 50A-00 amber faceplate	MPL1128
	Universal faceplate - blank cover	MPLFP00
	Universal faceplate - 20A	MPLFP20
	Universal faceplate - 30A	MPLFP30
	Universal faceplate - 50A	MPLFP50
	Lighthouse/Lighthouse SS breaker plate	MPL1141
	Powerhouse/Powerhouse SS breaker plate	RV1112


Power

	Description	Catalog #
	Powerhouse/Powerhouse SS 30A-50A receptacle plate	RV114335
	Powerhouse/Powerhouse SS 30A-00 and 50A-00 receptacle plate	RV11433
	Newport Harbor Mate 30A-30A faceplate Newport Harbor Mate 30A-30A GFCI faceplate	MPL1135 MPL1135-GF
	Newport Harbor Mate 30A-50A faceplate Newport Harbor Mate 30A-50A GFCI faceplate	MPL1136 MPL1136-GF
	Newport Harbor Mate 50A-50A faceplate Newport Harbor Mate 50A-50A GFCI faceplate	MPL1137 MPL1137-GF
	Newport Harbor Mate 50A-00 faceplate Newport Harbor Mate 50A-00 GFCI faceplate	MPL1138 MPL1138-GF
	Newport Harbor Mate 30A-00 faceplate Newport Harbor Mate 30A-00 GFCI faceplate	MPL1139 MPL1139-GF
	Newport Harbor Mate 30A-20 faceplate Newport Harbor Mate 30A-20 GFCI faceplate	MPL11392 MPL11392-GF

Description	Catalog #	
	Newport Harbor Mate 30A-30A-20 faceplate Newport Harbor Mate 30A-30A-20 GFCI faceplate	MPL1150 MPL1150-GF
	Newport Harbor Mate 50A-20 faceplate Newport Harbor Mate 50A-20 GFCI faceplate	MPL11382 MPL11382-GF
	Newport Harbor Mate 30A-50A-20 faceplate	MPL1151
	Newport Harbor Mate 30A-50A-20 GFCI faceplate	MPL1151-GF
	Newport Camp Mate 30A-30A-20GFI faceplate	RVPH1135
	Newport Camp Mate 30A-50A-20GFI faceplate	RVPH1136
	Newport Camp Mate 50A-50A-20GFI faceplate	RVPH1137
	Newport Camp Mate 50A-20GFI faceplate	RVPH1138







Power

Description	Catalog #
-------------	-----------














Newport Camp Mate 30A-20GFI faceplate

RVPH1139








Description	Catalog #	
<u>Lighthouse Faceplate Assemblies</u>		
	Lighthouse/Lighthouse SS 20A GFCI-00 amber faceplate assembly with breakers	MPL1120A
	Lighthouse/Lighthouse SS 30A-00 amber faceplate assembly with breakers Lighthouse/Lighthouse SS 30A-00 amber faceplate assembly with GFCI breakers	MPL1129A MPL1129A-GF
	Lighthouse/Lighthouse SS 30A-20GFCI amber faceplate assembly with breakers Lighthouse/Lighthouse SS 30A-20GFCI amber faceplate assembly with GFCI breakers	MPL1121A MPL1121A-GF
	Lighthouse/Lighthouse SS 30A-50A amber faceplate assembly with breakers Lighthouse/Lighthouse SS 30A-50A amber faceplate assembly with GFCI breakers	MPL1122A MPL1122A-GF
	Lighthouse/Lighthouse SS 30A-30A amber faceplate assembly with breakers Lighthouse/Lighthouse SS 30A-30A amber faceplate assembly with GFCI breakers	MPL1127A MPL1127A-GF
	Lighthouse/Lighthouse SS 50A-50A amber faceplate assembly with breakers	MPL1123A
	Lighthouse/Lighthouse SS 50A-20GFCI amber faceplate assembly with breakers Lighthouse/Lighthouse SS 50A-20GFCI amber faceplate assembly with GFCI breakers	MPL1124A MPL1124A-GF






Power

Description	Catalog #	
	Lighthouse/Lighthouse SS 20GFCI-20GFCI amber faceplate assembly with breakers	MPL1125A
	Lighthouse/Lighthouse SS 50A-00 amber faceplate assembly with breakers Lighthouse/Lighthouse SS 50A-00 amber faceplate assembly with GFCI breakers	MPL1128A MPL1128A-GF
	Lighthouse SS 100A 1F faceplate assembly with breakers and plate	MPL1142XA
	Lighthouse/Lighthouse SS 100A 3F faceplate assembly with breakers and plate (120/208V) Lighthouse/Lighthouse SS 100A 3F faceplate assembly with breakers and plate (480V) Lighthouse/Lighthouse SS 100A 3F faceplate assembly with breakers and plate (277/480V)	MPL1142YA MPL1142YA4 MPL1142YA24
	Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 20GFI flipcover assembly with breaker	MPL1131
	Hatteras Light 30A faceplate assemblies Hatteras Light 50A 250V faceplate assemblies	MPL1131-2 MPL1131-4








Description	Catalog #	
Powerhouse Faceplate Assemblies		
	Powerhouse/Powerhouse SS 30A-20GFCI faceplate assembly with breakers	RVPH1121A
	Powerhouse/Powerhouse SS 50A-20GFCI faceplate assembly with breakers	RVPH1124A
	Powerhouse/Powerhouse SS 30A-50A-20GFCI faceplate assembly with breakers	RVPH1122A
	Powerhouse/Powerhouse SS 30A-30A-20GFCI faceplate assembly with breakers	RVPH1123A
	Powerhouse/Powerhouse SS 50A-50A-20GFCI faceplate assembly with breakers	RVPH1125A






Power

Description	Catalog #
Newport Harbor Mate Faceplate Assemblies (for units w/stand)	
	MPL1135A-2
Newport Harbor Mate 30A-30A faceplate assembly with breakers (for units w/ stand) Newport Harbor Mate 30A-30A faceplate assembly with GFCI breakers (for units w/ stand)	MPL1135A-GF
	MPL1136A-2
Newport Harbor Mate 30A-50A faceplate assembly with breakers (for units w/ stand) Newport Harbor Mate 30A-50A faceplate assembly with GFCI breakers (for units w/ stand)	MPL1136A-GF
	MPL1137A-2
Newport Harbor Mate 50A-50A faceplate assembly with breakers (for units w/ stand) Newport Harbor Mate 50A-50A faceplate assembly with GFCI breakers (for units w/ stand)	MPL1137A-GF
	MPL1138A-2
Newport Harbor Mate 50A-00 faceplate assembly with breakers (for units w/ stand) Newport Harbor Mate 50A-00 faceplate assembly with GFCI breakers (for units w/ stand)	MPL1138A-GF
	MPL1139A-2
Newport Harbor Mate 30A-00 faceplate assembly with breakers (for units w/ stand) Newport Harbor Mate 30A-00 faceplate assembly with GFCI breakers (for units w/ stand)	MPL1139A-GF
	MPL1150A-2
Newport Harbor Mate 30A-30A-20GFI faceplate assembly with breakers (for units w/ stand) Newport Harbor Mate 30A-30A-20GFI faceplate assembly with GFCI breakers (for units w/ stand)	MPL1150A-GF
	MPL1151A-2
Newport Harbor Mate 30A-50A-20GFI faceplate assembly with breakers (for units w/ stand) Newport Harbor Mate 30A-50A-20GFI faceplate assembly with GFCI breakers (for units w/ stand)	MPL1151A-GF






Description	Catalog #
Newport Harbor Mate Faceplate Assemblies (for units w/stand)	
	MPL1152A-2
<p>Newport Harbor Mate 50A-50A-20GFI faceplate assembly with breakers (for units w/ stand) Newport Harbor Mate 50A-50A-20GFI faceplate assembly with GFCI breakers (for units w/ stand)</p>	MPL1152A-GF
	MPL1153A-2
<p>Newport Harbor Mate 50A-20GFI faceplate assembly with breakers (for units w/ stand) Newport Harbor Mate 50A-20GFI faceplate assembly with GFCI breakers (for units w/ stand)</p>	MPL1153A-GF
	MPL1154A-2
<p>Newport Harbor Mate 30A-20GFI faceplate assembly with breakers (for units w/ stand) Newport Harbor Mate 30A-20GFI faceplate assembly with GFCI breakers (for units w/ stand)</p>	MPL1154A-GF
	MPL1155A-2
<p>Newport Harbor Mate 50A-20GFI-20GFI faceplate assembly with breakers (for units w/ stand) Newport Harbor Mate 50A-20GFI-20GFI faceplate assembly with GFCI breakers (for units w/ stand)</p>	MPL1155A-GF
	MPL1156A-2
<p>Newport Harbor Mate 30A-20GFI-20GFI faceplate assembly with breakers (for units w/ stand) Newport Harbor Mate 30A-20GFI-20GFI faceplate assembly with GFCI breakers (for units w/ stand)</p>	MPL1156A-GF






Power

Description	Catalog #
Newport Harbor Mate Faceplate Assemblies (for stand-less units)	
	MPL1135A
Newport Harbor Mate 30A-30A faceplate assembly with breakers (for stand-less units) Newport Harbor Mate 30A-30A faceplate assembly with GFCI breakers (for stand-less units)	MPL1135A-GF
	MPL1136A
Newport Harbor Mate 30A-50A faceplate assembly with breakers (for stand-less units) Newport Harbor Mate 30A-50A faceplate assembly with GFCI breakers (for stand-less units)	MPL1136A-GF
	MPL1137A
Newport Harbor Mate 50A-50A faceplate assembly with breakers (for stand-less units) Newport Harbor Mate 50A-50A faceplate assembly with GFCI breakers (for stand-less units)	MPL1137A-GF
	MPL1138A
Newport Harbor Mate 50A-00 faceplate assembly with breakers (for stand-less units) Newport Harbor Mate 50A-00 faceplate assembly with GFCI breakers (for stand-less units)	MPL1138A-GF
	MPL1139A
Newport Harbor Mate 30A-00 faceplate assembly with breakers (for stand-less units) Newport Harbor Mate 30A-00 faceplate assembly with GFCI breakers (for stand-less units)	MPL1139A-GF
	MPL1150A
Newport Harbor Mate 30A-30A-20GFI faceplate assembly with breakers (for stand-less units) Newport Harbor Mate 30A-30A-20GFI faceplate assembly with GFCI breakers (for stand-less units)	MPL1150A-GF
	MPL1151A
Newport Harbor Mate 30A-50A-20GFI faceplate assembly with breakers (for stand-less units) Newport Harbor Mate 30A-50A-20GFI faceplate assembly with GFCI breakers (for stand-less units)	MPL1151A-GF

Description	Catalog #
<u>Newport Harbor Mate Faceplate Assemblies (for stand-less units)</u>	
	MPL1152A
<p>Newport Harbor Mate 50A-50A-20GFI faceplate assembly with breakers (for stand-less units) Newport Harbor Mate 50A-50A-20GFI faceplate assembly with GFCI breakers (for stand-less units)</p>	MPL1152A-GF
	MPL1153A
<p>Newport Harbor Mate 50A-20GFI faceplate assembly with breakers (for stand-less units) Newport Harbor Mate 50A-20GFI faceplate assembly with GFCI breakers (for stand-less units)</p>	MPL1153A-GF
	MPL1154A
<p>Newport Harbor Mate 30A-20GFI faceplate assembly with breakers (for stand-less units) Newport Harbor Mate 30A-20GFI faceplate assembly with GFCI breakers (for stand-less units)</p>	MPL1154A-GF
	MPL1155A
<p>Newport Harbor Mate 50A-20GFI-20GFI faceplate assembly with breakers (for stand-less units) Newport Harbor Mate 50A-20GFI-20GFI faceplate assembly with GFCI breakers (for stand-less units)</p>	MPL1155A-GF
	MPL1156A
<p>Newport Harbor Mate 30A-20GFI-20GFI faceplate assembly with breakers (for stand-less units) Newport Harbor Mate 30A-20GFI-20GFI faceplate assembly with GFCI breakers (for stand-less units)</p>	MPL1156A-GF









Power

Description	Catalog #
<u>Newport Camp Mate Faceplate Assemblies (for stand-less units)</u>	
	RV1150A
	RV1151A
	RV1152A
	RV1153A
	RV1154A





Description	Catalog #
<u>Newport Camp Mate Faceplate Assemblies (for stand-less units)</u>	
	Newport Camp Mate 30A-30A-20GFI faceplate assembly with breakers (for stand-less units) RV1150A-2
	Newport Camp Mate 30A-50A-20GFI faceplate assembly with breakers (for stand-less units) RV1151A-2
	Newport Camp Mate 50A-50A-20GFI faceplate assembly with breakers (for stand-less units) RV1152A-2
	Newport Camp Mate 50A-20GFI faceplate assembly with breakers (for stand-less units) RV1153A-2
	Newport Camp Mate 30A-20GFI faceplate assembly with breakers (for stand-less units) RV1154A-2









Power

	Description	Catalog #
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 20A 125V 1-pole	MPL1020
	Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 20A 125V 1-pole GFCI (30mA GFP)	MPLGF1020
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 30A 125V 1-pole	MPL1030
	Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 30A 125V 1-pole GFCI (30mA GFP)	MPLGF1030
	Ground fault breaker (W1), 30A 1-pole	MPLGF1030W1
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 50A 125V 1-pole	MPL1050
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 20A 125/250V 2-pole	MPL2020
	Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 20A 125/250V 2-pole GFCI (30mA GFP)	MPLGF2020

Description	Catalog #
	<p>Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht</p> <p>30A 125/250V 2-pole</p> <p>MPL2030</p>
	<p>Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht</p> <p>30A 125/250V 2-pole GFCI (30mA GFP)</p> <p>MPLGF2030</p>
	<p>Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht</p> <p>50A 125/250V 2-pole</p> <p>MPL2050</p>
	<p>Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht</p> <p>50A 125/250V 2-pole GFCI (30mA GFP)v</p> <p>MPLGF2050</p>
	<p>Ground fault breaker (W1), 50A 2-pole</p> <p>MPLGF2050W1</p>
	<p>Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht</p> <p>60A 125/250V 2-pole</p> <p>MPL2060</p>
	<p>Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht</p> <p>100A 125/250V 2-pole 100A 125/250V 2-pole, no terminals</p> <p>MPL2100 MPL2100D</p>
	<p>Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht</p> <p>100A 120/208V 3-pole 100A 120/208V 3-pole, no terminals</p> <p>MPL3100 MPL3100D</p>









Power

	Description	Catalog #
	Lighthouse/Lighthouse SS breaker filler, 1-pole space	MPL1141BF
	Hatteras ground fault adapter plate	MPL0002
	Admiral • Megayacht 200A 480V 3-pole	MPL2200
	Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht Transient voltage surge suppressor	MPLTVSS

Description	Catalog #
	Deckhand • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 20A GFCI duplex MPL3038
	Deckhand • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 30A 125V locking receptacle MPL3039
	Deckhand • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 50A 125V locking receptacle MPL3040
	Deckhand • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 50A 125/250V locking receptacle MPL3045
	Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 100A 120/240V pin and sleeve (15 degree slant) MPL4100R12W
	Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 100A 120/208V pin and sleeve (15 degree slant) MPL5100R9W
	Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 100A 480V 4-wire pin and sleeve (15 degree slant) MPL4100R7W
	Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 100A 480V 5-wire pin and sleeve (15 degree slant) MPL5100R7W









Connections

	Description	Catalog #
	Admiral • Megayacht 200A 480V 4-wire pin and sleeve (Russell-Stoll)	MPL4200R7W
	Newport Camp Mate • Powerhouse • Powerhouse SS 30A 125V RV	RV3042
	Newport Camp Mate • Powerhouse • Powerhouse SS 50A 125/250V RV	RV3043
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht Coax Cable TV female adapter with plastic insert	MPL1086
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht RJ45 CAT 5E High-speed internet jack	MPL3059
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht Marine phone receptacle	MPL3037
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht RJ12 CAT 3 phone jack	RV3060
	Pedestal cable assembly	MPL1161







Description	Catalog #	
	Lighthouse marine phone assembly with plate	MPL1166
	Lighthouse cable assembly with plate	MPL1160
	Lighthouse complete phone and cable assembly	MPL1114
	Pedestal marine phone assembly	MPL1167
	Pedestal phone assembly	MPL1168
	Pedestal cable assembly with plate	MPL1171
	Pedestal internet assembly	MPL1163
	Pedestal internet assembly with plate	MPL1162









Connections

	Description	Catalog #
	Hatteras Light • Lighthouse SS Pedestal marine phone and cable assembly	MPL1119S
	Pedestal phone and cable assembly	MPL1174
	Pedestal phone and internet assembly	MPL1176
	Pedestal phone and internet assembly with plate	MPL1175
	Pedestal cable and internet assembly	MPL1165
	Pedestal cable and internet assembly with plate	MPL1164
	Pedestal phone, cable, and internet assembly	MPL1180
	Pedestal phone, cable, and internet assembly with plate	MPL1179









Description	Catalog #	
	Newport marine phone assembly	MPL1169
	Newport phone assembly	MPL1170
	Newport cable assembly	MPL1172
	Newport internet assembly	MPL1173
	Newport Harbor Mate phone and cable insert assembly	MPL1115
	Newport phone and internet assembly	MPL1177
	Newport cable and internet assembly	MPL1178
	Newport marine phone, internet, and cable assembly	MPL1181



Connections

	Description	Catalog #
	Newport phone, internet, and cable assembly	MPL1182
	Powerslide CATV plate assembly	RV1130
	Powerslide internet plate assembly	RV1132
	Powerslide CATV/internet plate assembly	RV1134
	Powerslide internet/phone plate assembly	RV1135
	Powerslide cable/phone plate assembly	RV1136











Description	Catalog #	
	<p>Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht • Firehouse</p> <p>LED bulb only</p>	MPLLEDB
	<p>Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht • Firehouse</p> <p>LED kit</p>	MPLLEDB1
	<p>Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht • Firehouse</p> <p>LED kit with photocell</p>	MPLLEDB2
	<p>Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS</p> <p>LED light kit with a top and lens (Amber) LED light kit with a top and lens (Blue) LED light kit with a top and lens (Clear) LED light kit with a top and lens (Red, no photocell)</p>	<p>MPLLEDB2-LH MPLLEDB2-LHB MPLLEDB2-LHC MPLLEDB2-LHR</p>
	<p>Newport Harbor Mate / Newport Camp Mate</p> <p>Newport LED light upgrade - (LED Light, photocell, wires, and new lens)</p>	MPLLED3
	<p>Lighthouse • Lighthouse SS • Hatteras Light</p> <p>LED brick (Red)</p>	MPLLED4
	<p>Mariner • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht</p> <p>In-line fuse (for pedestals)</p>	MPL3026
	<p>Mariner • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht</p> <p>In-line fuse holder (for pedestals)</p>	MPL3027








Lighting

	Description	Catalog #
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht Photocell with nut and washer	MPL3044
	Newport Harbor Mate / Newport Camp Mate • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht Photocell nut and washer only	MPL3034
	Mariner • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS Light bulb socket (screw type)	MPL3079S
	Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS Screw socket bracket	MPL3080
	Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Firehouse Amber lens Clear lens Blue lens Red lens	MPL6005 MPL6008 MPL6008B MPL6005R
	Newport Harbor Mate amber lens (3-piece) Newport Harbor Mate blue lens (3-piece) Newport Harbor Mate clear lens (3-piece)	MPL1117 MPL1117B MPL1117C
	Admiral amber lens kit (8-piece) Admiral clear lens kit (8-piece) Admiral blue lens kit (8-piece)	MPL6016 MPL6018 MPL6018B
	Mariner LED top assembly (amber) Mariner LED top assembly (blue) Mariner LED top assembly (clear)	MPL6103-A MPL6103-B MPL6103-C









Description	Catalog #	
	Mariner • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS 9 Watt fluorescent bulb (pre 2010) 13 Watt fluorescent bulb (pre 2010)	MPL3017 MPL3018
	Firehouse red strobe light/siren	MPL3020









Water

	Description	Catalog #
	Lighthouse/Powerhouse water mounting plate with mounting brackets	MPL1132
	Lighthouse complete water manifold assembly (Single 3/4" hose bib w 1/4-turn ball valve)	MPL11A
	Powerhouse complete water manifold assembly (Single 3/4" hose bib w 1/4-turn ball valve)	RVPH11A
	Lighthouse complete water manifold assembly (Dual 3/4" hose bibs with 1/4-turn ball valves)	MPL11B
	Powerhouse complete water manifold assembly (Dual 3/4" hose bibs with 1/4-turn ball valves)	RVPH11B
	LHSS single water assembly	MPL11E
	LHSS dual water assembly	MPL11F
	Lighthouse SS/Powerhouse SS water mounting plate - blank	MPLSS1132
	Lighthouse SS/Powerhouse SS water mounting plate - 1 water spigot	MPLSS1132-1
	Lighthouse SS/Powerhouse SS water mounting plate - 2 water spigots	MPLSS1132-2









Description	Catalog #	
	Water mounting plate U-brackets and screws	MPL1132UB
	Hatteras Light 1/2" water mounting plate Hatteras Light 3/4" water mounting plate	MPL6585 MPL6584
	Hatteras Light 1/2" brass silcock (hose bib)	MPL 7014
	3/4" stainless steel ball valve (hose bib)	MPL5271
	Watts 3/4" backflow preventer	MPL7015
	Powerslide Powerslide water plate assembly	RV1140
	Water meters (new style)	MPL20WM









Housing

	Description	Catalog #
	Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS Top only	MPL6003
	Powerslide Powerslide top	RV6010
	MP&L logo	MPLLOGO
	MP&L generic flip cover lid	MPL0001
	Deckhand • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 20A GFCI external cover assembly	MPL1101
	Deckhand • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 30A receptacle external cover assembly	MPL1102
	Deckhand • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht 50A receptacle external cover assembly	MPL1105
	Deckhand • Hatteras Light • Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS • Admiral • Megayacht External breaker cover set - 1-pole, 2-pole, and 3-pole	MPL11061








Description	Catalog #	
	Lighthouse main door assembly kit Powerhouse main door assembly kit	MPL6007 RVPH6007
	Lighthouse SS main door Powerhouse SS main door	MPL6007S RVPH6007S
	Lighthouse SS/Powerhouse SS base mounting plate	MPL6009
	Lighthouse/Powerhouse top isolation plate	MPL6012
	Powerslide Powerslide main door assembly with amber lens	RV6050
	Powerslide Powerslide lower access panel	RV6052
	Powerslide Powerslide breaker faceplate	RV6054
	Powerslide Powerslide receptacle faceplate	RV6056

Housing

	Description	Catalog #
	Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS Stainless steel spring closure and hardware	MPL1099H
	Aluminum hose and cable bracket (One)	MPL1087
	Lighthouse/Powerhouse resin hose and cable bracket (One)	MPL1087R
	Lighthouse/Powerhouse pedestal base with bus bar holder and four blank access panels	MPL6004
	Powerslide post mount extension	RV6080
	Powerslide pad mount extension for single sided unit	RV6082
	Powerslide pad mount extension kit for dual sided unit	RV6083
	Powerslide direct burial extension	RV6084

Description	Catalog #	
	Lighthouse/Powerhouse aluminum blank access panel	MPL5500
	Lighthouse SS blank stainless steel access panel	MPLSS5500
	Lighthouse base extension (Height 10 inches) Lighthouse base extension (Height 12 inches) Lighthouse base extension (Height 14 inches) Hatteras Light base extension (10 inches)	MPL5502-10 MPL5502-12 MPL5502-14 MPL5502HL-10
	Newport Harbor Mate dock box beauty plate Newport Camp Mate dock box beauty plate	MPL5503 MPL5503N
	Lighthouse/Powerhouse base cap	MPL5504
	Newport Camp Mate main door Newport Harbor Mate main door	RVPH6001 MPL6001
	Powerhouse direct burial mount Powerhouse SS direct burial mount	RVPH5507 RVPH5507S
	Lighthouse / Powerhouse • Lighthouse SS / Powerhouse SS TVSS blank cover plate	MPL5508
	Newport Harbor Mate/Newport Camp Mate mounting brackets	MPL7005

Housing

Description	Catalog #
	Firehouse door MPL6013
	Firehouse 24" life ring MPL4201 Firehouse 30" life ring MPL4201-30
	Firehouse life ring bracket MPL4201B
	Firehouse blank access panel MPL6015
	Firehouse door/life ring switch MPL3050
	Firehouse door hasp MPL3950
	Firehouse 10-lb. ABC-Type fire extinguisher MPL8025 Firehouse 20-lb. ABC-Type fire extinguisher MPL8025X

Eaton Marina Power & Lighting Warranty Information

I. SCOPE

This is an addendum to Eaton Corporation's Selling Policy 25-000, modifying the Warranty Article only. All other terms and conditions are in accordance with Selling Policy 25-000.

Warranty for Internal Components for Eaton-Marina Power & Lighting Products: Eaton-Marina Power & Lighting internal component products are covered under the warranty set forth in Seller's Selling Policy 25-000.

II. WARRANTY PERIOD

Seller warrants that the housings of all Pedestals manufactured by it ("Housings") will conform to Seller's applicable specifications and be free from failure due to defects in workmanship and material for a period of five (5) years from the date of first sale or delivery, whichever is earlier.

Except for the Housings warranty provided herein, Seller does not provide any warranty on the Pedestal or any component therein. The meters in the Pedestals are manufactured by EZMeter ("EZMeter") and come with a separate five (5) year limited warranty from EZMeter against defects in workmanship and material in the meters. Seller does not warrant the meters, expressly disclaims any obligation under the EZMeter limited warranty on the meters, and does not administer claims under the EZMeter limited warranty. Any issues regarding the EZMeter meters should be addressed directly to EZMeter.

III. APPLICABILITY OF WARRANTY

In the event a Meter fails to comply with the foregoing warranty Seller will, at its option, either (a) repair or replace the defective Meter, or defective part or component thereof, F.O.B. Seller's facility freight prepaid, or (b) credit Buyer for the purchase price of the Product. All warranty claims for Meters shall be made in writing. Seller requires all non-conforming Products be returned at Seller's expense for evaluation unless specifically stated otherwise in writing by Seller.

****Remote Metering: Seller does not cover warranty for remote metering software or service.** All warranty claims for remote metering software and/or service must be directed to the respective manufacturer/provider. Seller warrants **only transmitters/transponder hardware and the install** in its pedestals according to the warranty set forth in Seller's Selling Policy 25-000.**

This warranty **does not** cover failure or damage due to storage, installation, operation, or maintenance not in conformance with Seller's recommendations and industry standard practice or **due to accident, misuse, overvoltage, submersion, abuse or negligence**. This warranty does not cover reimbursement for labor, gaining access, removal, installation, temporary

Eaton Marina Power & Lighting Warranty Information

power or any other expenses, which may be incurred in connection with repair or replacement. This Warranty is void if factory seal is broken.

This warranty does not cover wire harnesses, Current Transformers (CTs) and counters. These components are covered under selling policy 25-000.

This warranty does not apply to equipment not manufactured by Seller. Seller limits itself to extending the same warranty it receives from the supplier.

IV. LIMITATION OF WARRANTY, REMEDIES AND LIABILITY

In the event the Housing fails to comply with the foregoing warranty Seller will, at its option, either (a) repair or replace the defective Housing, or defective part or component thereof, F.O.B. Seller's facility freight prepaid, or (b) credit Buyer for the purchase price of the Product. All warranty claims for Housings shall be made in writing. Seller requires all non-conforming Products be returned at Seller's expense for evaluation unless specifically stated otherwise in writing by Seller.

This warranty does not cover failure or damage due to shipping, storage, installation, operation or maintenance **not** in conformance with Seller's recommendations and industry standard practice or **due to accident, misuse, overvoltage, submersion, abuse or negligence**. This warranty does not cover reimbursement for labor, gaining access, removal, installation, temporary power or any other expenses, which may be incurred in connection with repair or replacement. Paint touch up maintenance maybe required over the life of the product and is the sole responsibility of the Buyer.

This warranty does not apply to equipment not manufactured by Seller. Seller limits itself to extending the same warranty it receives from its suppliers.

Operation and Maintenance for Marina Power and Lighting® Units

Marina Power and Lighting® produces units that are designed to withstand the harsh marine exterior environment. Very little maintenance is required to keep the units looking new for many years and to keep the warranty effective.

I. Exterior Maintenance:

1. To remove dirt, grime, and bird droppings, use a mild solution of dishwashing detergent at approximately one teaspoon per gallon of warm water.
2. DO NOT use any solvent or corrosion inhibiting products on any part of the unit. This can cause serious stress cracking of the engineered resins.

II. Interior Maintenance:

1. Before attempting the following maintenance procedures, turn off the power to the unit at the power supply panel (note the breakers on the unit DO NOT turn the unit power supply off and the bus bars will be energized).

A. Exposing the Bus Bar Assembly:

- Lighthouse® & Powerhouse®: Annually, the four screws holding the top of the unit to the base should be removed and the unit should be tilted over to expose the bus bar area.
- Lighthouse SS: Annually, remove the access panel (14 screws) to expose the bus bars.
- Hatteras®: Annually, remove the light assembly (4 screws at base of light) and the plastic barrier to expose the bus bars.
- Newport Harbor Mate & Camp Mate: Annually, remove the light assembly at the bottom of the unit to expose the bus bars.

B. Maintenance of Bus Bar Assembly:

- On all units, the bus bars should be visually examined for excessive heating. If potentially faulty or loose joints are found, they should be tightened or replaced.

Maintenance and Cleaning

C. If Mechanical Lugs are Used Instead of the Stud-Lug Bus Assembly:

- In the cases where mechanical lugs instead of the stud-lug bus assembly are used, it is very important that they be examined closely. Most mechanical lugs are made of aluminum and are very susceptible to galvanic corrosion. If the set screw cannot be tightened, replace the lug. If there appears to be corrosion around the copper to aluminum connection, remove the copper wire and clean the wire, coat the wire with an anti-corrosion grease, and retighten the assembly.
2. The receptacles and breakers should be examined annually, and if any sign of heating is evident, the receptacles or breakers should be replaced.
 3. DO NOT spray any solvents on the electrical components. Solvents will cause stress cracking of the polymeric materials.

III. Lighting Assembly:

1. To test the lighting assembly, the photocell should be covered with a piece of black tape and in about 2-3 minutes the light should illuminate. If this does not occur, the following items should be checked: photocell, bulb, and ballast.

IV. Winterizing:

1. The water system should be purged with air and each ball valve should be opened and closed after the system has been drained. This will remove the slug of water that remains in the ball.

V. Operation:

1. Insert the proper end of the shore power cord into the boat's power inlet connection, twist the plug to lock, then tighten the locking plug retainer by twisting the large nut until the unit is tight to the boat.
2. With the breakers off, insert the shore power cord into the receptacle and twist the plug clockwise until the plug locks into the receptacle.
3. With both connections secured, turn on the breaker. The power indicator on the boat should indicate a successful attachment of the plug and the receptacle.

03-01-19



Eaton
 1000 Eaton Boulevard
 Cleveland, OH 44122
 United States
 Eaton.com

Eaton Corporation
 Marina Power and Lighting
 149 Warwick Court
 Williamsburg, VA 23185
 United States
 www.marinapower.com

Eaton is a registered trademark.

All other trademarks are property of their respective owners.

© 2021 Eaton
 All Rights Reserved
 Printed in USA
 Publication No. BR620025EN
 September 2021



Powering Business Worldwide