
YARM24 INSTALLATION INSTRUCTIONS



Thank you for buying RAB lighting fixtures. Our goal is to design the best quality products to get the job done right. We'd like to hear your comments. Call the Marketing Department at 888-RAB-1000 or email: marketing@rabweb.com



IMPORTANT

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

Fixtures must be wired in accordance with the National Electrical Code and all applicable local codes. Proper grounding is required for safety. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.


WARNING: Make certain power is OFF before installing or maintaining fixture.

LOCATION

Select a location on a structurally sound, flat wall or pole. Fixture should be located on wall or pole at least 18" below any overhang or other structural detail. Fixture must not be recessed.

YARM24 MOUNTING

- Secure the Interlocking Mounting Clamps around the YARM24 using the provided truss screws, locknuts and hex-nuts.
- Mount the YARM24 to a sturdy wall. Using the mounting template on the YARM24 mounting plate as a guide, mark the 4 mounting holes. Drill 3/16" pilot holes and use provided Lag Bolts (4) to mount to wooden surface or use appropriate mounting hardware (not supplied) suitable for the mounting surface.
- 3. Secure the **YARM24** in the **Housing Arm** by following installation directions on fixture instruction sheet.
- 4. Follow wiring directions on fixture installation instruction sheet to complete electrical splices.




Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.



YARM24 INSTALLATION INSTRUCTIONS



Thank you for buying RAB lighting fixtures. Our goal is to design the best quality products to get the job done right. We'd like to hear your comments. Call the Marketing Department at 888-RAB-1000 or email: marketing@rabweb.com



IMPORTANT

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

Fixtures must be wired in accordance with the National Electrical Code and all applicable local codes. Proper grounding is required for safety. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.


WARNING: Make certain power is OFF before installing or maintaining fixture.

LOCATION

Select a location on a structurally sound, flat wall or pole. Fixture should be located on wall or pole at least 18" below any overhang or other structural detail. Fixture must not be recessed.

YARM24 MOUNTING

- Secure the Interlocking Mounting Clamps around the YARM24 using the provided truss screws, locknuts and hex-nuts.
- Mount the YARM24 to a sturdy wall. Using the mounting template on the YARM24 mounting plate as a guide, mark the 4 mounting holes. Drill 3/16" pilot holes and use provided Lag Bolts (4) to mount to wooden surface or use appropriate mounting hardware (not supplied) suitable for the mounting surface.
- 3. Secure the **YARM24** in the **Housing Arm** by following installation directions on fixture instruction sheet.
- 4. Follow wiring directions on fixture installation instruction sheet to complete electrical splices.



Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.

