



T8 LED LAMPS

DESCRIPTION

13W T8 4' LED | 3000K, 3500K, 4000K, 5000K | > 83 CRI

Single- or Double-ended Wiring | Ballast and Line-Voltage Compatible













LAMP TYPE: Linear **BULB TYPE: T8 LED** BASE TYPE: G13 (Medium Bi-Pin) **WATTAGE: 13W COLOR TEMPERATURE:** 3000K, 3500K, 4000K, 5000K **COLOR RENDERING INDEX (CRI): 83**



WARRANTY: 5 Years **PRODUCT FEATURES**

- Plug & Play application: Compatible with most instant- and programmed-start electronic T8 ballasts
- Dimmable with compatible dimming ballasts (See Compatibility List)
- Lamp is dimmable in Type B mode when used with an appropriate dimming accessory (purchased separately). Contact Keystone for more details to find out what is best for the intended application.
- Bypass ballast application: Runs on 120–277 line voltage
- Can be used with step down transformer for 480V to 120V/277V
- Frosted lens eliminates pixelation


- Environmentally friendly: No mercury used
- 50,000+ hour lifetime
- Instant startup
- Operating temperature: -20°C/-4°F to 45°C/113°F
- Suitable for dry and damp indoor locations
- UL Listed
- ETL Sanitation Listed NSF/ANSI Standard 2 Food Equipment, Splash Zone (Not for Direct Food Zone without additional fixture considerations)

OPERATING SPECIFICATIONS


	ССТ	CRI	Bare Lamp Wattage	Instant-Start Ballast-Compatible Application						Line-Voltage Application					
Catalog Number				Input Voltage	System Wattage*		Initial Lumens*			Input	Lamp	Initial	Max THD	Power Factor	
					0.78BF	0.88BF	1.18BF	0.78BF	0.88BF	1.18BF	Voltage	Wattage	Lumens		
KT-LED13T8-48G-830-X3	3000K	83	13W	Ballast dependent	13.5W	15.5W	23.0W	1650 lm	1850 lm	2550 lm	120-277V	13W	1850 lm	20%	>0.9
KT-LED13T8-48G-835-X3	3500K	83	13W	Ballast dependent	13.5W	15.5W	23.0W	1700 lm	1900 lm	2650 lm	120-277V	13W	1900 lm	20%	>0.9
KT-LED13T8-48G-840-X3	4000K	83	13W	Ballast dependent	13.5W	15.5W	23.0W	1750 lm	1950 lm	2700 lm	120-277V	13W	1950 lm	20%	>0.9
KT-LED13T8-48G-850-X3	5000K	83	13W	Ballast dependent	13.5W	15.5W	23.0W	1750 lm	1950 lm	2700 lm	120-277V	13W	1950 lm	20%	>0.9

^{*} Nominal values. Actual values may vary depending on electronic ballast used.

SPECTRAL DISTRIBUTION



POLAR CANDELA DISTRIBUTION



PHOTOMETRIC CHARACTERISTICS

СС	Т	CRI	Luminous Flux	Efficacy	Beam Angle		
3000	OΚ	83	1850 lm	142 lm/W	160°		
3500	ΣK	83	1900 lm	146 lm/W	160°		
4000	ΣK	83	1950 lm	150 lm/W	160°		
5000	ΣK	83	1950 lm	150 lm/W	160°		



50,000

L70 (Hours) 80° H: Max Candela 90° H 0° H

Maximum Candela = 1299.2 Located at Horizontal Angle = 80°, Vertical Angle = 4°





T8 LED LAMPS


INSTALLATION INSTRUCTIONS

DIRECT REPLACEMENT (WITH EXISTING BALLAST)

- 1. Turn power off.
- 2. Remove lens or diffuser, if applicable.
- 3. Remove existing fluorescent lamp(s) from the luminaire.
- 4. Install the LED replacement lamp(s), one lamp for each fluorescent lamp removed*.
- 5. Replace lens or diffuser back in place, if applicable.
- 6. Turn power back on.
- * Warning: Check Keystone's Ballast Compatibility List before installation

BY-PASS REPLACEMENT (WITH BALLAST REMOVED)

- A. Disconnect power from fixture.
- B. Remove fluorescent lamps.
- C. Remove lens and wiring compartment, if applicable.
- D. Cut all wires connected to ballast (see Figure A: Typical Ballast Configurations).
- E. Identify what type of lamp holders are in fixture: non-shunted lamp holders or shunted lamp holders (see **Figure B**: *Lamp Holder Types*). Double-ended wiring installations of Keystone Combo Drive X3 tubes can be used with shunted G13 or non-shunted G13 lamp holders with instructions to externally shunt.



PROGRAM START Lamp Lamp Red Yellow Yellow Ballast Red Blue Line Blue PREHEAT WITH STARTER S Lamp Ballast Line **INSTANT START** Lamp Lamp Ballast Red Line Blue Neutral Blue CAUTION: Instant start ballasts have shunted lamp holders.


FIGURE A Typical Ballast Configurations

Caution: For single-ended wiring use only non-shunted lamp holders.

For Single-ended wiring, do not install product in a fixture with shunted lamp

holders (found in all fixtures using instant start ballasts). If the current lamp holders are shunted, remove them and replace them with non-shunted lamp holders. Make new connections directly to terminals as indicated above.

Keystone can provide any style replacement lamp holders. Call us at 800-464-2680.







T8 LED LAMPS

WIRING DIAGRAMS

DOUBLE-ENDED LINE VOLTAGE WIRING

Single lamp

- 1. Follow steps A-C (see By-Pass Replacement (with ballast removed), on page 2).
- 2. Cut all existing connections to ballast and remove ballast (see Figure A, on page 2, for typical ballast configurations).
- 3. Connect line voltage AC to both pins on Side A of the lamp (marked L and N1) on the endcap as shown below; on Side B, connect line neutral AC wire to pins marked N2 and N3 on the endcap as shown below (see **Figure C**, on page 2, for Direct Drive LED tube connection pins).






- 4. Complete all electrical connections with appropriate connectors/wire nuts as needed, per all local and national electrical codes. *Note:* there should not be any exposed wires from sockets left unconnected.
- 5. Replace wiring compartment cover.
- 6. Ensure that installed lamp is wired to line and neutral in the lamp holder and that lamp is facing proper direction for illumination.
- 7. Install lens or diffuser, if applicable.
- 8. Apply power to fixture and check for illumination.

Multiple lamps

- 1. Follow steps A-C (see By-Pass Replacement (with ballast removed), on page 2).
- 2. Cut all existing connections to ballast and remove ballast (see Figure A, on page 2, for typical ballast configurations).
- 3. Connect the terminals of the first lamp to the matching terminals of the second lamp with line and neutral wires. Continue daisy-chain connection for each additional lamp as shown below.



- 4. Complete all electrical connections with appropriate connectors/wire nuts as needed, per all local and national electrical codes. *Note:* there should not be any exposed wires from sockets left unconnected.
- 5. Replace wiring compartment cover.
- 6. Ensure that installed lamp is wired to line and neutral in the lamp holder and that lamp is facing proper direction for illumination.
- 7. Install lens or diffuser, if applicable.
- 8. Apply power to fixture and check for illumination.

(wiring diagrams continued on next page)





T8 LED LAMPS

WIRING DIAGRAMS (continued)

SINGLE-ENDED LINE VOLTAGE WIRING*

Note: For single-ended wiring installations, power is applied *only* to endcap labeled Side A. **Do NOT** apply power to Side B.

Single lamp

- 1. Follow steps A-C (see By-Pass Replacement (with ballast removed), on page 2).
- Cut all existing connections to ballast and remove ballast (see Figure A, on page 2, for typical ballast configurations).
 Note: Single-ended wiring requires non-shunted lamp holders (see Figure B, on page 2, for lamp holder types).
- 3. On Side A of lamp holder, connect line voltage AC wire to pin marked L and connect line neutral AC wire to pin marked N1 on the endcap as shown below (see **Figure C**, on page 3, for Direct Drive LED tube connection pins). Do not connect AC wires to Side B.




*Caution: Use only non-shunted lamp holders for single-ended wiring installations. Do not perform single-ended wiring installation of product in a fixture with shunted lamp holders (found in all fixtures using instant-start ballasts). If the existing lamp holders are shunted and single-ended wiring is desired, remove and replace them with non-shunted lamp holders (or remove the external shunt, if applicable), Make new connections directly to lamp holder terminals as shown on this page).

- 4. Complete all electrical connections with appropriate connectors/wire nuts as needed, per all local and national electrical codes. *Note:* there should not be any exposed wires from sockets left unconnected.
- 5. Replace wiring compartment cover.
- 6. Ensure that installed lamp is wired to line and neutral in the lamp holder and that lamp is facing proper direction for illumination.
- 7. Install lens or diffuser, if applicable.
- 8. Apply power to fixture and check for illumination.

Multiple lamps

- 1. Follow steps A-C (see By-Pass Replacement (with ballast removed), on page 2).
- 2. Cut all existing connections to ballast and remove ballast (see **Figure A**, on page 2, for typical ballast configurations). *Note:* Single-ended wiring requires non-shunted lamp holders.
- 3. Connect the terminals of the first lamp to the matching terminals of the second lamp with line and neutral wires. Continue daisy-chain connection for each additional lamp as shown below. *Note:* Do not connect any wires to Side B of lamp holder.




- 4. Complete all electrical connections with appropriate connectors/wire nuts as needed, per all local and national electrical codes. *Note:* there should not be any exposed wires from sockets left unconnected.
- 5. Replace wiring compartment cover.
- 6. Ensure that installed lamp is wired to line and neutral in the lamp holder and that lamp is facing proper direction for illumination.
- 7. Install lens or diffuser, if applicable.
- 8. Apply power to fixture and check for illumination.





T8 LED LAMPS

PHYSICAL CHARACTERISTICS



LAMP DIMENSIONS

A (Body Length)	47.15"
B (Illuminated Length)	42.63"
C (Diameter)	1.10"

NOMINAL LENGTH: 48"

BASE TYPE: G13 (Medium Bi-Pin)

ORDERING INFORMATION

ORDER CODE	PACK QTY.	EASY CODE	UPC	DLC PRODUCT ID
KT-LED13T8-48G-830-X3	25	EDX-28	843654129433	PL69Z8RT40R0
KT-LED13T8-48G-835-X3	25	JXL-65	843654129440	PL8KGHMLNKMX
KT-LED13T8-48G-840-X3	25	CZQ-98	843654129457	PLT7217R1GO2
KT-LED13T8-48G-850-X3	25	MOF-22	843654129464	PLSJ0WM9WVNX

CATALOG NUMBER BREAKDOWN

KT-LED13T8-48G-8XX-X3

- 1 Keystone Technologies
- 2 LED Lamp
- 3 Wattage
- 4 Lamp Type
- 5 Nominal Length (Inches)
- **6** Glass Construction
- 7 80 CRI
- **8** Color Temperature
- 9 Single- or Double-Ended Line Voltage and Ballast Compatible