LED-8032M

Installations Instruction



SKU	Description		
LED-8032M30-A	140W High Bay LED, 120-277V, 3000K		
LED-8032M40-A	140W High Bay LED, 120-277V, 4000K	331	
LED-8032M57-A	140W High Bay LED, 120-277V, 5700K	0	
LED-8032M30C-A	140W High Bay LED, 347V, 3000K		
LED-8032M40C-A	140W High Bay LED, 347V, 4000K	<u> </u>	L
LED-8032M57C-A	140W High Bay LED, 347V, 5700K		9.055"

Contents:

- 1 PCS LED Retrofit lamp
- 1 PCS Re-lamping label

1 PCS Installation instructions

Read this before you start installation:

- 1. To avoid possible electric shock, power supply must be turned off at fuse box or circuit breaker before installing or servicing.
- Check your local electrical code. This code sets wiring standards for your area and should carefully studied before starting installation. High voltage wiring connecting the fixture must have a temperature rated minimum of 194°F.
- 3. Inspect existing fixture:
 - Fixtures gaskets/seals must be able to prevent water and insects from entering enclosed fixture.
 - Fixture meets minimum size requirements listed at right.
 - Ballast must be bypassed or removed.
- 4. Consider installing surge/lightning protectors where high lightning activity is present or at facilities where over voltages are common.

INSTALLATION REQUIREMENTS

Input	120-277VAC (USA)		
Voltage	347VAC ("C" Models)		
Frequency	50/60Hz		
Lamp Holder	EX39 or E39		
	Outdoor Luminaires		
Approved	(Fully enclosed or with cover or		
Fixtures and	lens to prevent entry of water)		
Locations	Indoor Luminaires		
	(Open or Fully Enclosed)		
	A <u>minimum</u> of 2" spacing		
Minimum	between lamp and fixture		
Fixture Size	housing is required to meet		
	heat rating of LED lamp		
Approved Lamp Orientations			
	Base Up Base Down Horizontal		
Moisture	UL approved for damp		
Rating	environments		

IMPORTANT SAFETY INSTRUCTIONS FOR LED RETROFIT CONVERSION:

FOR USE ONLY WITH HID LUMINAIRES IN ACCORDANCE WITH THE INSTRUCTIONS PROVIDED WITH THIS RETROFIT KIT.

WARNING - RISK OF FIRE OR ELECTRICAL SHOCK. LED retrofit kit installation requires knowledge of the existing luminaire's electrical design.

- **WARNING RISK OF FIRE OR ELECTRICAL SHOCK.** Install this kit only in luminaires that have the features and dimensions shown in the requirements box.
- WARNING Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.
- **WARNING -** To prevent wiring damage or abrasion, do not expose wiring to sharp edges of housing or other sharp surface.
- **WARNING -** Suitable for DAMP LOCATIONS. **Not for use with magnetic ballast.** SUITABLE FOR USE IN ENCLOSED LUMINAIRES.

THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS.



188 S. Northwest Highway • Cary, IL 60013 (847) 380-3540 • FAX: (847) 380-3542 www.led-llc.com LED-8032M

Installations Instruction



Electrical System Guidance


It is highly recommended that a licensed electrical contractor/electrician be used to install the LED retrofit lamp Installation:

- Step 1: **Disconnect Electrical Power to fixture.**
- Step 2: Remove or wire past the HID ballast.
- Step 3: Lamp can operate on any voltage from 120V through 277V or 347V (C models). Connect the two common wires from the power source directly to the corresponding leads to the socket. NOTE: The screw of the lamp holder (not the center contact point) shall be connected to the NEUTRAL wire (white or gray)

	Voltage	<u>Wiring Breakdown</u>	
	120V, 277V, & 347V	One (1) Hot, One (1) Neutral	
	208V & 240V	Two (2) Hots	
	480V	You must add 480V-277V Autotransformer	
		to convert circuit to 277V	
ep 4:	Thread the retrofit lamp onto the female socket of the existing		

- Ste luminaire. Do Not over-torque socket, will cause damage to lamp! Apply the silver adhesive label to the inside of the luminaire where it Step 5:
 - will be visible during re-lamping.
- Step 6: Turn on electrical power to the fixture.

Wiring Diagram





188 S. Northwest Highway • Cary, IL 60013 (847) 380-3540 • FAX: (847) 380-3542 www.led-llc.com

tor