

CW LIGHTING, LLC 7701 West Little York Rd, Suite 300 HOUSTON TX 77040 Phone: (713) 690-9320 Fax: (713) 690-4805

Job Name Elliott - Stock Luminaires - SF150-SCT-T CWL24-100713

> Bid Date Apr 22, 2024

Submittal Date Apr 22, 2024

Distributor: ELLIOTT - HOUSTON 7929 N Sam Houston Pkwy W Houston TX 77064

	CW Lighting louston, TX 77040 713.690.9320		Transmittal CW LIGHTING, LLC 7701 West Little York Rd, Suite 300 HOUSTON TX 77040 Phone: (713) 690-9320 From: MICHAEL THOMPSON
Project Quote# Location To	Elliott - Stock Lumi CWL24-100713 ELLIOTT ELECTRIC 7929 N Sam Housto SUITE 200 Houston TX 77064 Contact:		
ATTACHE		G YOU 1 COPY OF THE FO Specifications Information Submittals	LLOWING ITEM: Other:
Prior / Appro	RE TRANSMITTED F Approval val val as Submitted val as Noted	FOR: ☐ Resubmittal for Approv ☐ Corrections ⊠ Your Use ☐ Review and Comment	Bids due on: Other:
Ту	r pe MFG SIGNIFY - S	Part STONCO SF150-SCT-T-G2-10-F	PCB-BZ

Submitted by CW LIGHTING, LLC CW Lighting Houston, TX 77040 713.690.9320	Catalog Number: SF150-SCT-T-G2-10- Notes:	PCB-BZ	Type: _{CWL24-100713}	
	Flo	odlights		
Stonco	SlimFlood dual select			
by §ignify	SF15/35/60/	/100/150/205/300		
			Project:	
The SlimFlood dual select offers energy s selectable color and wattage. Versatile a		Location:		
choose from, provides application flexibil		Cat.No: Type:		
installations. Ideal for sign lighting, buildi	y lighting, and	Lamps:	Qty:	
general purpose floodlighting applicatior		Notes:		

Ordering guide

example: SF35-SCT-K-G2-10-PCB-BZ

Lumina	^{ire} 150	сст S (СТ	Mounting T	Ger	G2	Ì	/oltage 10	Options PCB]	Fini E	sh 3Z
SF15	SlimFlood S 15W	SCT	CCT Selectable	K Knucle Mount ¹	G2	Gen 2	1	IO 120-347V	-	None ³ (SF15 only)	ΒZ	Bronze
SF35	SlimFlood DS 15-25-35W		(3000K, 4000K, 5000K)	Y Yoke Mount ¹					РСВ	Photocell ⁴		
SF60	SlimFlood DS 15-35-60W	-		(SF15, SF35, and SF60 only)						(SF35, SF60, SF100, SF150 only)		
SF100	SlimFlood DS 60-80-100W			S Slipfitter Mount ²								
SF150	SlimFlood DS 100-120-150W			T Trunnion Mount ²								
SF205	SlimFlood DS 120-150-205W			(SF100, SF150, SF205, and	1				-	Photocell Ready,		
SF300	SlimFlood DS 205-255-300W			SF300 only)						Photocell sold separately as		
										SFW205-300-PCB ⁵		
										(SF205 and SF300 only)		

1. Knuckle & Yoke mount options standard for SF15, SF35 and SF60 only.

2. Slipfitter & Trunnion mount options for SF100, SF150, SF205 and SF300 only.

3. Photocell option not available for SF15.

4. Photocell is included as standard for SF35, SF60, SF100, SF150 with an ON/OFF switch.

5. Photocell option can be purchased as a separate accessory for SF205 & SF300 use code SF205-300-PCB.

LED Wattage and Lumen Values

Ordering Guide	Color Temp. (K) ¹	Average System Wattage ³	Lumen Output ^{3,4}	Efficacy (LPW)
SF15	4000	15W ²	21751m	145
SF35	4000	15/25/35W	2370/3800/5075lm	145
SF60	4000	15/35/60W	2370/5320/8700lm	145
SF100	4000	60/80/100W	9540/12320/14800lm	145
SF150	4000	100/120/150W	15800/18240/21750lm	145
SF205	4000	120/150/205W	18600/22500/29725lm	145
SF300	4000	205/255/300W	31775/38250/43500lm	145

1. Color temperature factory setting is 4000K.

2. Wattage/Lumen Output factory setting set to mid power option.


3. SF15 is none wattage selectable.


4. Wattage and lumen output may vary by +/10% due to actual input voltage.

5. Lumen values based on photometric tests performed in compliance with IESNA LM-79.




Stonco_SlimFloodDS_SpecSheet 01/23 page1of5





Stonco_SlimFloodDS_SpecSheet 01/23 page 3 of 5





Job Name:

Elliott - Stock Luminaires - SF150-SCT-T Distributor: ELLIOTT - HOUSTON (Houston) Catalog Number: SF150-SCT-T-G2-10-PCB-BZ

CWL24-100713

SF15/35/60/100/150/205/300

SlimFlood LED dual select 15-300W

Specifications

Housing and Heat Sink

Single piece aluminum alloy die cast housing.

Mounting

Suitable for mounting within 4' (1.2m) of the ground.

Knuckle (K, see Ordering guide): Integral die cast Aluminum adjustable knuckle (K) with locking teeth and bolt to lock in aiming angle. Ships fully assembled, ready to install. Knuckle mount option standard for SF15, SF35 and SF60 only.

Yoke (Y, see Ordering guide): Integral structural steel adjustable Yoke (Y) for direct surface mounting, painted for resistance to corrosion, with bolt to lock in aiming angle. Ships fully assembled, ready to install. Yoke mount option standard for SF15, SF35 and SF60 only.

Trunnion (T, see Ordering guide): Integral structural steel adjustable trunnion (T) for direct surface mounting, painted for resistance to corrosion, with bolt to lock in aiming angle. Ships fully assembled, ready to install. Trunnion mount option for SF100, SF150, SF205 and SF300 only.

Slipfitter (S, see Ordering guide): Integral die cast Aluminum adjustable slipfitter (S) includes set screws for securing luminaire to tenon, with aiming angle markings and bolt to lock in aiming angle. Ships fully assembled, ready to install. Slipfitter mount option for SF100, SF150, SF205 and SF300 only.

Lens

15W - 150W Tempered glass lens 205W - 300W Polycarbonate lens

Light Engine

Composed of 3 main components: LED Module / Optical System / Driver. Electrical components are RoHS compliant.

Notes:

Color Temperature

All luminaires are provided with three field selectable color temperature options: 3000K/4000K (Default)/5000K.

Wattage

SlimFlood dual select is provided with wattage field adjustable options.

SF15: 15W(Default); SF35: 15-25(Default)-35W; SF60: 15-35(Default)-60W; SF100: 60-80(Default)-100W; SF150: 100-120(Default)-150W; SF205: 120-150(Default)-205W; SF300: 205-255(Default)-300W.

Driver

Slim Flood dual select operates with a 120-347V; 50/60Hz Class 1 or Class 2 driver. All configurations operate with 0-10V dimming.

Other Integrated Features

Photocell: Included as standard for SF35, SF60, SF100, SF150 with an ON/OFF switch in the luminaire and can be purchased as a separate field installable accessory for SF205 & SF300 using code SF205-300-PCB.

Surge Protection: Each luminaire is provided as standard with surge protection. 15-60W: 2.5kV; 100-150W: 4kV; 205-300W: 6kV.

Beam Angle: 15-150W and 300W - 110°; 205W - 100°; Tolerance: +/-15%.

Finish

Fade and abrasion resistant powdercoat bronze finish (RAL 8019).

Certifications and Compliance

cULus Listed for Canada and USA. DLC 5.1 Premium. Entire luminaire is rated for operation in ambient temperature of -40° C (-40° F) up to $+50^{\circ}$ C ($+122^{\circ}$ F)

IP65 Rating

Entire luminaire including light engine and driver/ electrical compartment IP65 rated in all aiming positions including upward aiming floodlighting applications.

Limited Warranty

5-year limited warranty. See signify.com/ warranties for details and restrictions. Visit our eCatalog or contact your local sales representative for more information.

Predicted Lumen Depreciation Data

Ambient Temperature °C	L ₇₀ per TM21 ^{1,2}
25°C	50,000hrs

1. $\rm L_{20}$ is the predicted time when LED performance depreciates to 70% of initial lumen output. 2. Calculated per IESNA TM 21-11. Published $\rm L_{20}$ hours limited to 6 times actual LED test hours.

(s)ignify

© 2023 Signify Holding. All rights reserved. The information provided herein is subject to change, without notice. Signify does not give any representation or warranty as to the accuracy or completeness of the information included herein and shall not be liable for any action in reliance thereon. The information presented in this document is not intended as any commercial offer and does not form part of any quotation or contract, unless otherwise agreed by Signify

Stonco_SlimFloodDS_SpecSheet 01/23 page 5 of 5

Signify North America Corporation 400 Crossing Blvd, Suite 600 Bridgewater, NJ 08807 Telephone: 855-486-2216

All trademarks are owned by Signify Holding or their respective owners.

www.stonco.com

281 Hillmount Road, Markham, ON, Canada L6C 2S3

Telephone: 800-668-9008

CW Lighting Houston TX 77040 Houston TX 77040	Catalog Number: SF150-SCT-T-G2-10-PCB-BZ Notes:	Type: CWL24-100713
Stoneo	Floodlighting	

Stonco	
KEENE	
by (Signify	

INSTALLATION INSTRUCTIONS

carefully read through this instruction sheet.Proper grounding is required to ensure

qualified licensed electrician. Keep these instructions.

regulations when install this fixture.

personal safety.

Before assembling your fixture, please make sure that you

Consider having your fixture installed by a

Do not use an electric generator to test LED fixtures.
 Please abide by related country, regional and local law and

Please turn off the power before installation or maintenance.
 Proper earth grounding is required to ensure safety.


 To avoid possibility of electrical shock or fire, the installation personnel must have professional electric knowledge.
 Please wear gloves to avoid injury before installation.
 If any smoke or spark of the wire happened, please turn off the power immediately and notify relevant personnel.


Slim Flood
SF15-SCT-K-G2-10-BZ
SF15-SCT-Y-G2-10-BZ
SF35-SCT-K-G2-10-PCB-BZ
SF35-SCT-Y-G2-10-PCB-BZ
SF60-SCT-K-G2-10-PCB-BZ
SF60-SCT-Y-G2-10-PCB-BZ

SF100-SCT-S-G2-10-PCB-BZ

SF100-SCT-T-G2-10-PCB-BZ	
SF150-SCT-S-G2-10-PCB-BZ	
SF150-SCT-T-G2-10-PCB-BZ	
SF205-SCT-S-G2-10-BZ	
SF205-SCT-T-G2-10-BZ	
SF300-SCT-S-G2-10-BZ	
SF300-SCT-T-G2-10-BZ	







ATTENTION

IMPORTANT


CAUTIONS

NOTICE

- 1. Please check if there is any damage during shipping. If so, please contact manufacturer timely.
- 2. Please read the installation instruction carefully to check whether all the accessories are complete. After confirmation, then install the fixture according to installation steps.

WIRING

- Make sure that the mains voltage is appropriate and conforms with the luminaire driver.
- Connect fixture GROUND (green) wire to power supply GROUND (green) wire.
- Connect fixture WHITE wire to power supply (-) COMMON wire.
- Connect fixture **BLACK** wire to power supply (+)LINE wire.
- Connect fixture **PURPLE** wire to power supply **DIM+** wire.
- Connect fixture **PINK** wire to power supply **DIM**- wire.



CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR CONSULTER UN ÉLECTRICIEN QUALIFIÉ POUR VOUS ASSURER QUE LES CONDUCTEURS DE LA DÉRIVATION SONT ADÉQUATS

Signify

© 2022 Signify Holding. All rights reserved. This document may be subject to change. No representation or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance thereon is disclaimed. All trademarks are owned by Signify Holding or their respective owners.

www.keene-lighting.com


Signify North America Corporation 400 Crossing Blvd, Suite 600 Bridgewater, NJ 08807 United States Telephone 855-486-2216 Signify Canada Ltd. 281 Hillmount Road, Markham, ON, Canada L6C 2S3 Telephone 800-668-9008

8/8/2022 page 1 www.stonco.com

Submitted On: Apr 22, 2024

6/9


Index Page



KNUCKLE MOUNT


- 1. Take the fixture out of package;
- 2. Finish the wire connection according to the right mode of connection (pay attention to positive wire, negative wire, and ground wire), (figure 1).and then put wire into lamp pole;(figure 2)
- 3. Loosen screws; Adjust fixture angles as per actual demands and tighten screws later; Angles of the fixture is adjustable (pass the bracket through mounting surface, fix it with screws, then connect the wires as perproper wiring requirements). (figure 3)

Notice: Adjustable angle is +/-90°(Figure 2)




- 1. Drill holes on the wall as shown. (Figure 4)
- 2. Knock the expansion bolts into the wall.(Figure 5)

3. Connect the fixture to the bracket and tighten the screws; connect the wires properly and put them into junction box.(Figure 5) Notice: Adjustable angle is +/-90°(Figure 6)



SLIPFITTER MOUNT

- Connect the wire correctly and put the wire into pole. Then fasten the locking bolts between slip fitter and the pole.(Figuer 7)
 Loosen the fixing bolts and adjusting bolts, align the fixture to required angle. Tighten adjusting bolts and fixing bolts (provided) after the angle in confirmed. (Figure 8)
- Notice: Adjustable angle is +/-90° (Figure 7)





www.keene-lighting.com

page 2

www.stonco.com


8/8/2022






PHOTOCELL AND FUNCTION FOR 205W & 300W

Attention: When the photocell function is required, it should be installed in the back of the fixture, please make sure to remove the shorting cap after installation, since if it is not removed, this will prevent photocell to work. Photocell is sold seperately for 205W&300W. (figure 15)



2. After adjusting the required conrol function, tighten the metal plug and the plastic plug clockwise. (figure 17)



PRODUCT CODE	POWER	ССТ	PHOTOCELL		
SF15-SCT-K-G2-10-BZ	NA				
SF15-SCT-Y-G2-10-BZ	NA .				
SF35-SCT-K-G2-10-PCB-BZ	H=35W.M=25W.L=15W				
SF35-SCT-Y-G2-10-PCB-BZ	11-3500,101-2500,12-1500				
SF60-SCT-K-G2-10-PCB-BZ	H=60W,M=35W,L=15W		ON= Photocell on OFF=Photocell off		
SF60-SCT-Y-G2-10-PCB-BZ		3K=3000K 4K=4000K 5K=5000K			
SF100-SCT-S-G2-10-PCB-BZ					
SF100-SCT-T-G2-10-PCB-BZ	H=100W,M=80W,L=60W				
SF150-SCT-S-G2-10-PCB-BZ	H=150W.M=120W.L=100W				
SF150-SCT-T-G2-10-PCB-BZ	11-15000,101-12000,1-10000				
SF205-SCT-S-G2-10-PCB-BZ	H=205W.M=150W.L=120W				
SF205-SCT-T-G2-10-PCB-BZ	11-203 VV,IVI-130 VV,L-120 VV				
SF300-SCT-S-G2-10-PCB-BZ	H=300W.M=255W.L=205W		*SOLD SEPARATELY		
SF300-SCT-T-G2-10-PCB-BZ	11-500 vv,ivi-255 vv,L-205 vv				

(s) ignify

© 2022 Signify Holding. All rights reserved. This document may be subject to change. No representation or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance thereon is disclaimed. All trademarks are owned by Signify Holding or their respective owners. Signify North America Corporation 400 Crossing Blvd, Suite 600 Bridgewater, NJ 08807 United States Telephone 855–486–2216 Signify Canada Ltd. 281 Hillmount Road, Markham, ON, Canada L6C 2S3 Telephone 800-668-9008

8/8/2022 page 2 www.stonco.com

Submitted On: Apr 22, 2024

www.keene-lighting.com



CW LIGHTING, LLC 7701 West Little York Rd, Suite 300 HOUSTON TX 77040 Phone: (713) 690-9320 Fax: (713) 690-4805

Job Name Elliott - Stock Luminaires - SF150-SCT-T CWL24-100713

> Bid Date Apr 22, 2024

Submittal Date Apr 22, 2024

Distributor: ELLIOTT - HOUSTON 7929 N Sam Houston Pkwy W Houston TX 77064

	CW Lighting Houston, TX 77040 713.690.9320				CW L 7701 HOU Phon	Ansmittal LIGHTING, LLC West Little York Rd, Suite 300 STON TX 77040 Ie: (713) 690-9320 In: MICHAEL THOMPSON
Project Quote# Location To	CWL24-100	713 ELECTRIC am Houston F 0		SF150-SCT-T	1101	
ATTACHE	ngs	E SENDING `	Spe	COPY OF THE FOL ecifications ormation omittals	LOWI	NG ITEM: Other:
☐ Prior / ☐ Appro ☐ Appro	Approval		□ Res □ Cor ⊠ You	submittal for Approva rections ir Use view and Comment	I	Record Bids due on: Other:
ту	/ре	MFG SIGNIFY - STO	ONCO	Part SF150-SCT-T-G2-10-PC	CB-BZ	

Submitted by CW LIGHTING, LLC CW Lighting Houston, TX 77040 713.690.9320	Catalog Number: SF150-SCT-T-G2-10- Notes:	PCB-BZ	Type: _{CWL24-100713}	
	Flo	odlights		
Stonco	SlimFlood dual select			
by §ignify	SF15/35/60/	/100/150/205/300		
			Project:	
The SlimFlood dual select offers energy s selectable color and wattage. Versatile a		Location:		
choose from, provides application flexibil		Cat.No: Type:		
installations. Ideal for sign lighting, buildi	y lighting, and	Lamps:	Qty:	
general purpose floodlighting applicatior		Notes:		

Ordering guide

example: SF35-SCT-K-G2-10-PCB-BZ

Luminaire SF150		CCT Mounting SCT T		Generation Voltage		Options PCB		Finish BZ				
SF15	SlimFlood S 15W	SCT	CCT Selectable	K Knucle Mount ¹	G2	Gen 2	1	IO 120-347V	-	None ³ (SF15 only)	ΒZ	Bronze
SF35	SlimFlood DS 15-25-35W		(3000K, 4000K, 5000K)	Y Yoke Mount ¹			Ι		РСВ	Photocell ⁴		
SF60	SlimFlood DS 15-35-60W			(SF15, SF35, and SF60 only)						(SF35, SF60, SF100, SF150 only)		
SF100	SlimFlood DS 60-80-100W			S Slipfitter Mount ²								
SF150	SlimFlood DS 100-120-150W			T Trunnion Mount ²								
SF205	SlimFlood DS 120-150-205W			(SF100, SF150, SF205, and]				-	Photocell Ready,		
SF300	SlimFlood DS 205-255-300W			SF300 only)						Photocell sold separately as		
										SFW205-300-PCB ⁵		
		1					1			(SF205 and SF300 only)		

1. Knuckle & Yoke mount options standard for SF15, SF35 and SF60 only.

2. Slipfitter & Trunnion mount options for SF100, SF150, SF205 and SF300 only.

3. Photocell option not available for SF15.

4. Photocell is included as standard for SF35, SF60, SF100, SF150 with an ON/OFF switch.

5. Photocell option can be purchased as a separate accessory for SF205 & SF300 use code SF205-300-PCB.

LED Wattage and Lumen Values

Ordering Guide	Color Temp. (K) ¹	Average System Wattage ³	Lumen Output ^{3,4}	Efficacy (LPW)
SF15	4000	15W ²	21751m	145
SF35	4000	15/25/35W	2370/3800/5075lm	145
SF60	4000	15/35/60W	2370/5320/8700lm	145
SF100	4000	60/80/100W	9540/12320/14800lm	145
SF150	4000	100/120/150W	15800/18240/21750lm	145
SF205	4000	120/150/205W	18600/22500/29725lm	145
SF300	4000	205/255/300W	31775/38250/43500lm	145

1. Color temperature factory setting is 4000K.

2. Wattage/Lumen Output factory setting set to mid power option.


3. SF15 is none wattage selectable.


4. Wattage and lumen output may vary by +/10% due to actual input voltage.

5. Lumen values based on photometric tests performed in compliance with IESNA LM-79.




Stonco_SlimFloodDS_SpecSheet 01/23 page1of5





Stonco_SlimFloodDS_SpecSheet 01/23 page 3 of 5





Job Name:

Elliott - Stock Luminaires - SF150-SCT-T Distributor: ELLIOTT - HOUSTON (Houston) Catalog Number: SF150-SCT-T-G2-10-PCB-BZ

CWL24-100713

SF15/35/60/100/150/205/300

SlimFlood LED dual select 15-300W

Specifications

Housing and Heat Sink

Single piece aluminum alloy die cast housing.

Mounting

Suitable for mounting within 4' (1.2m) of the ground.

Knuckle (K, see Ordering guide): Integral die cast Aluminum adjustable knuckle (K) with locking teeth and bolt to lock in aiming angle. Ships fully assembled, ready to install. Knuckle mount option standard for SF15, SF35 and SF60 only.

Yoke (Y, see Ordering guide): Integral structural steel adjustable Yoke (Y) for direct surface mounting, painted for resistance to corrosion, with bolt to lock in aiming angle. Ships fully assembled, ready to install. Yoke mount option standard for SF15, SF35 and SF60 only.

Trunnion (T, see Ordering guide): Integral structural steel adjustable trunnion (T) for direct surface mounting, painted for resistance to corrosion, with bolt to lock in aiming angle. Ships fully assembled, ready to install. Trunnion mount option for SF100, SF150, SF205 and SF300 only.

Slipfitter (S, see Ordering guide): Integral die cast Aluminum adjustable slipfitter (S) includes set screws for securing luminaire to tenon, with aiming angle markings and bolt to lock in aiming angle. Ships fully assembled, ready to install. Slipfitter mount option for SF100, SF150, SF205 and SF300 only.

Lens

15W - 150W Tempered glass lens 205W - 300W Polycarbonate lens

Light Engine

Composed of 3 main components: LED Module / Optical System / Driver. Electrical components are RoHS compliant.

Notes:

Color Temperature

All luminaires are provided with three field selectable color temperature options: 3000K/4000K (Default)/5000K.

Wattage

SlimFlood dual select is provided with wattage field adjustable options.

SF15: 15W(Default); SF35: 15-25(Default)-35W; SF60: 15-35(Default)-60W; SF100: 60-80(Default)-100W; SF150: 100-120(Default)-150W; SF205: 120-150(Default)-205W; SF300: 205-255(Default)-300W.

Driver

Slim Flood dual select operates with a 120-347V; 50/60Hz Class 1 or Class 2 driver. All configurations operate with 0-10V dimming.

Other Integrated Features

Photocell: Included as standard for SF35, SF60, SF100, SF150 with an ON/OFF switch in the luminaire and can be purchased as a separate field installable accessory for SF205 & SF300 using code SF205-300-PCB.

Surge Protection: Each luminaire is provided as standard with surge protection. 15-60W: 2.5kV; 100-150W: 4kV; 205-300W: 6kV.

Beam Angle: 15-150W and 300W - 110°; 205W - 100°; Tolerance: +/-15%.

Finish

Fade and abrasion resistant powdercoat bronze finish (RAL 8019).

Certifications and Compliance

cULus Listed for Canada and USA. DLC 5.1 Premium. Entire luminaire is rated for operation in ambient temperature of -40° C (-40° F) up to $+50^{\circ}$ C ($+122^{\circ}$ F)

IP65 Rating

Entire luminaire including light engine and driver/ electrical compartment IP65 rated in all aiming positions including upward aiming floodlighting applications.

Limited Warranty

5-year limited warranty. See signify.com/ warranties for details and restrictions. Visit our eCatalog or contact your local sales representative for more information.

Predicted Lumen Depreciation Data

Ambient Temperature °C	L ₇₀ per TM21 ^{1,2}
25°C	50,000hrs

1. $\rm L_{20}$ is the predicted time when LED performance depreciates to 70% of initial lumen output. 2. Calculated per IESNA TM 21-11. Published $\rm L_{20}$ hours limited to 6 times actual LED test hours.

(s)ignify

© 2023 Signify Holding. All rights reserved. The information provided herein is subject to change, without notice. Signify does not give any representation or warranty as to the accuracy or completeness of the information included herein and shall not be liable for any action in reliance thereon. The information presented in this document is not intended as any commercial offer and does not form part of any quotation or contract, unless otherwise agreed by Signify

Stonco_SlimFloodDS_SpecSheet 01/23 page 5 of 5

Signify North America Corporation 400 Crossing Blvd, Suite 600 Bridgewater, NJ 08807 Telephone: 855-486-2216

All trademarks are owned by Signify Holding or their respective owners.

www.stonco.com

281 Hillmount Road, Markham, ON, Canada L6C 2S3

Telephone: 800-668-9008

		Catalog Number:		Туре:		
LIGHTING Hou	CW Lighting Houston, TX 77040 713.690.9320 JOb Name: Elliott - Stock Luminaires - SF150-SCT-T Distributor: ELLIOTT - HOUSTON (Houston)		SF150-SCT-T-G2-10-PCB-BZ Notes:		CWL24-100713	
		G1 0 m 00		Floodlighting		
Stonco				Slim Flood		

Stonco
KEENE
by (signify

INSTALLATION INSTRUCTIONS

carefully read through this instruction sheet.Proper grounding is required to ensure

qualified licensed electrician. Keep these instructions.

regulations when install this fixture.

personal safety.

Before assembling your fixture, please make sure that you

Consider having your fixture installed by a

Do not use an electric generator to test LED fixtures.
 Please abide by related country, regional and local law and

Please turn off the power before installation or maintenance.
 Proper earth grounding is required to ensure safety.


 To avoid possibility of electrical shock or fire, the installation personnel must have professional electric knowledge.
 Please wear gloves to avoid injury before installation.
 If any smoke or spark of the wire happened, please turn off the power immediately and notify relevant personnel.


Slim
SF15-SCT
SF15-SCT


SF15-SC1-K-G2-10-BZ	
SF15-SCT-Y-G2-10-BZ	
SF35-SCT-K-G2-10-PCB-BZ	
SF35-SCT-Y-G2-10-PCB-BZ	
SF60-SCT-K-G2-10-PCB-BZ	
SF60-SCT-Y-G2-10-PCB-BZ	
SF100-SCT-S-G2-10-PCB-BZ	

C2 40 D

SF100-SCT-T-G2-10-PCB-BZ SF150-SCT-S-G2-10-PCB-BZ SF150-SCT-T-G2-10-PCB-BZ SF205-SCT-S-G2-10-BZ SF205-SCT-S-G2-10-BZ SF300-SCT-T-G2-10-BZ SF300-SCT-T-G2-10-BZ







ATTENTION

IMPORTANT


CAUTIONS

NOTICE

- 1. Please check if there is any damage during shipping. If so, please contact manufacturer timely.
- 2. Please read the installation instruction carefully to check whether all the accessories are complete. After confirmation, then install the fixture according to installation steps.

WIRING

- Make sure that the mains voltage is appropriate and conforms with the luminaire driver.
- Connect fixture GROUND (green) wire to power supply GROUND (green) wire.
- Connect fixture WHITE wire to power supply (-) COMMON wire.
- Connect fixture **BLACK** wire to power supply (+)LINE wire.
- Connect fixture **PURPLE** wire to power supply **DIM+** wire.
- Connect fixture **PINK** wire to power supply **DIM**- wire.



CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR CONSULTER UN ÉLECTRICIEN QUALIFIÉ POUR VOUS ASSURER QUE LES CONDUCTEURS DE LA DÉRIVATION SONT ADÉQUATS

Signify

© 2022 Signify Holding. All rights reserved. This document may be subject to change. No representation or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance thereon is disclaimed. All trademarks are owned by Signify Holding or their respective owners.

www.keene-lighting.com


Signify North America Corporation 400 Crossing Blvd, Suite 600 Bridgewater, NJ 08807 United States Telephone 855-486-2216 Signify Canada Ltd. 281 Hillmount Road, Markham, ON, Canada L6C 2S3 Telephone 800-668-9008

8/8/2022 page 1 www.stonco.com

Submitted On: Apr 22, 2024

6/9


Index Page



KNUCKLE MOUNT


- 1. Take the fixture out of package;
- 2. Finish the wire connection according to the right mode of connection (pay attention to positive wire, negative wire, and ground wire), (figure 1).and then put wire into lamp pole;(figure 2)
- 3. Loosen screws; Adjust fixture angles as per actual demands and tighten screws later; Angles of the fixture is adjustable (pass the bracket through mounting surface, fix it with screws, then connect the wires as perproper wiring requirements). (figure 3)

Notice: Adjustable angle is +/-90°(Figure 2)




- 1. Drill holes on the wall as shown. (Figure 4)
- 2. Knock the expansion bolts into the wall.(Figure 5)

3. Connect the fixture to the bracket and tighten the screws; connect the wires properly and put them into junction box.(Figure 5) Notice: Adjustable angle is +/-90°(Figure 6)



SLIPFITTER MOUNT

- Connect the wire correctly and put the wire into pole. Then fasten the locking bolts between slip fitter and the pole.(Figuer 7)
 Loosen the fixing bolts and adjusting bolts, align the fixture to required angle. Tighten adjusting bolts and fixing bolts (provided) after the angle in confirmed. (Figure 8)
- Notice: Adjustable angle is +/-90° (Figure 7)





www.keene-lighting.com

page 2

www.stonco.com


8/8/2022






PHOTOCELL AND FUNCTION FOR 205W & 300W

Attention: When the photocell function is required, it should be installed in the back of the fixture, please make sure to remove the shorting cap after installation, since if it is not removed, this will prevent photocell to work. Photocell is sold seperately for 205W&300W. (figure 15)



2. After adjusting the required conrol function, tighten the metal plug and the plastic plug clockwise. (figure 17)



PRODUCT CODE	POWER	ССТ	PHOTOCELL	
SF15-SCT-K-G2-10-BZ	NA			
SF15-SCT-Y-G2-10-BZ	NA		ON= Photocell on	
SF35-SCT-K-G2-10-PCB-BZ	H=35W.M=25W.L=15W			
SF35-SCT-Y-G2-10-PCB-BZ	11-3500;101-2500;1-1500			
SF60-SCT-K-G2-10-PCB-BZ	H=60W,M=35W,L=15W			
SF60-SCT-Y-G2-10-PCB-BZ	H-0000,101-3300,L-1300	3к=3000к	OFF=Photocell off	
SF100-SCT-S-G2-10-PCB-BZ	H=100W.M=80W.L=60W	4K=4000K		
SF100-SCT-T-G2-10-PCB-BZ	H=10000,101-8000,L=6000			
SF150-SCT-S-G2-10-PCB-BZ	H=150W.M=120W.L=100W	5K=5000K		
SF150-SCT-T-G2-10-PCB-BZ	11-13000,101-12000,1-10000			
SF205-SCT-S-G2-10-PCB-BZ	H=205W.M=150W.L=120W			
SF205-SCT-T-G2-10-PCB-BZ	11-203 00,101-13000,1-12000			
SF300-SCT-S-G2-10-PCB-BZ	H=300W.M=255W.L=205W		*SOLD SEPARATELY	
SF300-SCT-T-G2-10-PCB-BZ	11-300 vv,ivi-233 vv,L-203 vv			

(s) ignify

© 2022 Signify Holding. All rights reserved. This document may be subject to change. No representation or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance thereon is disclaimed. All trademarks are owned by Signify Holding or their respective owners.

www.keene-lighting.com

Signify North America Corporation 400 Crossing Blvd, Suite 600 Bridgewater, NJ 08807 United States Telephone 855–486–2216 Signify Canada Ltd. 281 Hillmount Road, Markham, ON, Canada L6C 2S3 Telephone 800-668-9008

8/8/2022 page 2 www.stonco.com

Submitted On: Apr 22, 2024